

## CATAMARAN SUP FRAME ASSEMBLY STEPS

Catamaran frame requires minimal assembly with included straps: 4 long, 4 medium, 4 short with buckles, 1 medium for motor mount, and plastic sliders.



Use provided backrests or optional beach chairs. Secure each beach chair with 4 optional lashing tie-downs. Or, inflate backrests to desired firmness and secure with Velcro.



Inflate the catamaran platform to 5-10 psi or until as hard as rock using the hand pump or optional electric inflator. Use either valve and ensure pushpins are locked in the upper position. To deflate quickly, open both valves and press the pushpins to release air.



Use a lashing tie-down with a buckle to secure the motor mount vertically, ensuring it is perpendicular to the platform.



Secure four medium-length straps to the backrest D-rings by threading them through the sliders to form and tighten loops.



1



2



3



4