



BEACH FOLDING HAMMOCK MANUAL

WARNING: Please watch your fingers when installing or folding hammock, as aluminum frame can pinch your fingers between tubes when frame ends swing together on hook bolts.

- Snap frame tubes together by sliding narrower ends of tubes into larger tubes. Make sure that each pushpin pops completely into its matching hole.
- Attach frame tubes in an order shown on below drawing. Holes and pushpins should face outside of frame.
- Pull assembled hammock tubes apart so that to provide reliable support. Adjust straps if necessary to provide adequate width between support tubes for best support.
- Attach hammock fabric loops over hook bolts, or use provided ropes. Fabric must be as tight as drum.
- Use WD40 periodically to make assembly/disassembly easier. Wipe with clean cloth when needed.



Please enter hammock not from center, but slightly toward rear, so that legs will not end up higher than a head.



WARNING: DO NOT exceed recommended maximum weight. NOT a toy. DO NOT use as a swing set. DO NOT jump into hammock. Place on a flat surface only. Improper use of this hammock can cause injury.